

MikroTik Set Up Guide



unⁱserve
constant | change

330 – 333 Terminal Avenue
Vancouver, BC V6A 4C1

Local: 604.395.3900

Toll Free: 1.844.395.3900

Email: info@uniserve.com

www.uniserve.com

1

The Mikrotik comes with a Power Supply and Ethernet cable. Before beginning, unplug your modem from power.



2

Connect one end of the Ethernet cable to Port 1 (Internet) on the Mikrotik.



3

Connect the other end of the Ethernet cable to your Modem.



4

Connect Power to the Mikrotik. The PWR light should turn green.



5

Connect Power to the Modem, wait for its online light to go solid.



6

Your Wireless should now be on. You can connect to the UniHub Wifi network you see on your devices.



UniHub-1234

Account: _____

SSID: _____ , _____

Password: _____

*UniHub5g - 5GHz signal provides faster data rates at a shorter distance, but may not be supported by all devices.

*UniHub - 2.4GHz signal offers coverage for farther distances, but may perform at slower speeds or suffer interference from other devices.